

# EVAL-ADG5298EB1Z User Guide

One Technology Way • P.O. Box 9106 • Norwood, MA 02062-9106, U.S.A. • Tel: 781.329.4700 • Fax: 781.461.3113 • www.analog.com

# Evaluating the ADG5298, High Temperature, High Voltage, Latch-Up Proof, 8-Channel Multiplexer

## **FEATURES**

Up to 210°C high temperature operation Supply voltages Dual supply: ±5 V to ±22 V Single supply: 8 V to 44 V Parallel interface compatible with 3 V logic

## **EVALUATION KIT CONTENTS**

**EVAL-ADG5298EB1Z** evaluation board

#### **ONLINE RESOURCES**

Documents Needed

ADG5298 data sheet

EVAL-ADG5298EB1Z user guide

## **EQUIPMENT NEEDED**

DC voltage source
±22 V for dual supply
44 V for single supply
Digital logic supply: 3 V to 5 V
Analog signal source
Method to measure voltage, such as a digital multimeter (DMM)

## **GENERAL DESCRIPTION**

The EVAL-ADG5298EB1Z is the evaluation board for the ADG5298 high temperature 8:1 multiplexer. The board assembly is constructed with high temperature compliant materials and is suitable for short duration evaluation up to 210°C.

Figure 1 shows the EVAL-ADG5298EB1Z in a typical evaluation setup. The ADG5298 is soldered to the center of the EVAL-ADG5298EB1Z evaluation board, and headers are provided to connect to each of the source and drain pins. A 4-pin header powers the device and provides a user defined digital logic supply voltage.

Full specifications on the ADG5298 are available in the ADG5298 data sheet, which should be consulted in conjunction with this user guide when using the EVAL-ADG5298EB1Z evaluation board.

## TYPICAL EVALUATION SETUP




Figure 1. EVAL-ADG5298EB1Z, Power Supply, and Signal Generator

## UG-1038

## EVAL-ADG5298EB1Z User Guide

## **TABLE OF CONTENTS**

Features	1
Evaluation Kit Contents	1
Online Resources	1
Equipment Needed	1
General Description	1
Typical Evaluation Setup	1
Revision History	2
Getting Started	3
Evaluation Board Setup Procedure	3
Evaluation Board Hardware	4
Power Supply	4

Input Signals	4
Board Construction	
Jumper Settings	
Switches and 0 $\Omega$ Resistors	
SMB Connectors	
•	
Decoupling Capacitors  Evaluation Board Schematics and Artwork  Ordering Information	 1

## **REVISION HISTORY**

9/2016—Revision 0: Initial Version

## **GETTING STARTED**

## **EVALUATION BOARD SETUP PROCEDURE**

The EVAL-ADG5298EB1Z evaluation board operates independently and does not require any additional evaluation boards or software to operate.

Supply the EVAL-ADG5298EB1Z evaluation board with a dual power source of up to  $\pm 22$  V or a single supply of up to  $\pm 44$  V by connecting VSS and GND together.

Take the following steps to set up a functionality test:

- 1. Connect a power supply to J10. Connect VSS and GND together if a single supply is required.
- 2. LK1 through LK4 control the digital signals for the ADG5298. See Table 1 for the logic control truth table.




Figure 2. EVAL-ADG5298EB1Z Block Diagram of the Main Components

## **EVALUATION BOARD HARDWARE**

The operation of the ADG5298 is evaluated using the EVAL-ADG5298EB1Z. Figure 1 shows a typical evaluation setup where only a power supply and signal generator are required. Figure 2 shows the block diagram of the main components of the EVAL-ADG5298EB1Z evaluation board.

Using this evaluation board, the ADG5298 passes signals from either the source or the drain connectors.

## **POWER SUPPLY**

Connector J10 provides access to the supply pins of the ADG5298. VDD, GND, and VSS on the J10 link to the appropriate pins on the ADG5298. For dual-supply voltages, the EVAL-ADG5298EB1Z evaluation board can be powered from ±5 V to ±22 V. For single-supply voltages, the GND and VSS terminals must be connected together, and the EVAL-ADG5298EB1Z evaluation board must be powered with 8 V to 44 V. In addition, use the J10 header to supply the voltage, VL, used to control the digital logic.

#### **INPUT SIGNALS**

Headers connect to both the source and drain pins of the ADG5298. Additional Subminiature Version B (SMB) connector pads are available if extra connections are required.

Each trace on the source and drain side includes two sets of 0805 pads, which can place a load on the signal path to ground. A 0  $\Omega$  resistor is placed in the signal path and can be replaced with a user defined value. The resistor combined with the 0805 pads can create a simple resistor capacitor (RC) filter.

The ADG5298 uses a parallel interface to control the operation of the switches. The switch operation can be manually controlled using the LK1 to LK4 switches, or an external controller can be interfaced directly to the control pins by using the SMB connector pads, if required (EN, A0, A1, and A2). See Table 1 for the logic control truth table.

## **BOARD CONSTRUCTION**

The board assembly uses high temperature rated components, including passives, connectors, printed circuit board (PCB) materials, and solder. By using a polyimide PCB laminate, it can handle a high glass transition temperature (T<sub>G</sub>), allowing it to maintain integrity at high temperatures where standard laminate deteriorates. The EVAL-ADG5298EB1Z evaluation board uses a Sn90Sb10 lead free solder due to its high melting point (245°C to 250°C). The EVAL-ADG5298EB1Z evaluation board also uses a nickel gold surface finish (plating) to avoid intermetallic formation between the tin in the solder and the copper PCB traces at high temperatures. In addition, the EVAL-ADG5298EB1Z evaluation board uses resistors, capacitors, and connectors rated for extended temperatures by their respective manufacturers. For further information on the EVAL-ADG5298EB1Z evaluation board construction, see the bill of materials in Table 3.

## JUMPER SETTINGS SWITCHES AND 0 Ω RESISTORS

Links control the ADG5298 manually. Table 1 and Table 2 show the truth table and the summary of the links.

Use LK2 to LK4 to control the switches of the ADG5298. Position L is tied to GND and sets the logic low, and Position H is tied to VL and sets the logic high.

Use LK1 to enable or disable the device. Position L is tied to GND and disables the device, and Position H is tied to VL and enables the device.

## **SMB CONNECTORS**

The parallel interface of the ADG5298 is controlled manually using the link headers (LK1 to LK4), or it can be accessed using the SMB front prints (EN, A0, A1, and A2). Note that these footprints are unpopulated.

## **DECOUPLING CAPACITORS**

The EVAL-ADG5298EB1Z evaluation board comes with 0.1  $\mu F$  decoupling capacitors populated on both the VDD and VSS power supplies, which provides sufficient decoupling for the ADG5298. However, if extra decoupling is needed due to for example, a noisy power supply, C4 and C6 can add additional decoupling capacitors.

Table 1. ADG5298 Truth Table

LK4 (A2)	LK3 (A1)	LK2 (A0)	LK1 (EN)	Connected Sx	
Don't care	Don't care	Don't care	Low	All switches off	
Low	Low	Low	High	S1	
Low	Low	High	High	S2	
Low	High	Low	High	S3	
Low	High	High	High	S4	
High	Low	Low	High	S5	
High	Low	High	High	S6	
High	High	Low	High	S7	
High	High	High	High	S8	

Table 2. Switch and 0  $\Omega$  Resistor Descriptions

Label	Position	Description
LK1	Low	Logic 0 on the EN pin
	High	Logic 1 on the EN pin
LK2	Low	Logic 0 on the A0 pin
	High	Logic 1 on the A0 pin
LK3	Low	Logic 0 on the A1 pin
	High	Logic 1 on the A1 pin
LK4	Low	Logic 0 on the A2 pin
	High	Logic 1 on the A2 pin

## **EVALUATION BOARD SCHEMATICS AND ARTWORK**







Figure 3. EVAL-ADG5298EB1Z Evaluation Board Schematic (Part 1)







GND1 GND2

Figure 4. EVAL-ADG5298EB1Z Evaluation Board Schematic (Part 2)




Figure 5. EVAL-ADG5298EB1Z Silkscreen




Figure 6. EVAL-ADG5298EB1Z Top Layer




Figure 7. EVAL-ADG5298EB1Z Bottom Layer

## ORDERING INFORMATION

#### **BILL OF MATERIALS**

#### Table 3.

Reference Designator	Description	Manufacturer Part Number	Stock Code
A0 to A2, EN, S1 to S8, D	50 Ω, straight, SMB jacks	Not applicable	Do not insert
C1 to C3, C5	0.1 μF ceramic capacitors, 100 V, NP0, 1210	C1210H104J1GACTU	Digi-Key 399-5748-2-ND
C4, C6	Through hole, electrolytic capacitors	Not applicable	Do not insert
T1 to T9, T_A0 to T_A2, T_EN, GND1, GND2	Test points	Not applicable	Do not insert
J1 to J9	Vertical, high temperature series, through hole, headers, 2-pin, 2.54 mm	YMC02SAAN	Digi-Key S9665-02-ND
J10	Vertical, high temperature series, through hole, headers, 4-pin, 2.54 mm	YMC04SAAN	Digi-Key S9665-04-ND
R1 to R9	0 Ω, 0805, 0.125 W, maximum operating temperature = 300°C	SPJ3003-0RN1	SPJ3003-0RN1
R10 to R27	SMD, 0805, resistors	Not applicable	Do not insert
LK1 to LK4	Vertical, high temperature series, through hole, headers, 3-pin, 2.54 mm and shorting link	YMC03SAAN and WDC02SXNN	Digi-Key S9665-03-ND and Digi-Key S9663-ND
U1	High temperature, high voltage, latch-up proof, 8-channel multiplexer	ADG5298HFRZ	ADG5298HFRZ
Not Applicable	Solder, Sn90Sb10 alloy	Indium Corporation Indalloy 259 solder paste, 8.9 HF	Not applicable



ESD (electrostatic discharge) sensitive device. Charged devices and circuit boards can discharge without detection. Although this product features patented or proprietary protection circuitry, damage may occur on devices subjected to high energy ESD. Therefore, proper ESD precautions should be taken to avoid performance degradation or loss of functionality.

By using the evaluation board discussed herein (together with any tools, components documentation or support materials, the "Evaluation Board"), you are agreeing to be bound by the terms and conditions set forth below ("Agreement") unless you have purchased the Evaluation Board, in which case the Analog Devices Standard Terms and Conditions of Sale shall govern. Do not use the Evaluation Board until you have read and agreed to the Agreement. Your use of the Evaluation Board shall signify your acceptance of the Agreement. This Agreement is made by and between you ("Customer") and Analog Devices, Inc. ("ADI"), with its principal place of business at One Technology Way, Norwood, MA 02062, USA. Subject to the terms and conditions of the Agreement, ADI hereby grants to Customer a free, limited, personal, temporary, non-exclusive, non-sublicensable, non-transferable license to use the Evaluation Board FOR EVALUATION PURPOSES ONLY. Customer understands and agrees that the Evaluation Board is provided for the sole and exclusive purpose referenced above, and agrees not to use the Evaluation Board for any other purpose. Furthermore, the license granted is expressly made subject to the following additional limitations: Customer shall not (i) rent, lease, display, sell, transfer, assign, sublicense, or distribute the Evaluation Board; and (ii) permit any Third Party to access the Evaluation Board. As used herein, the term "Third Party" includes any entity other than ADI, Customer, their employees, affiliates and in-house consultants. The Evaluation Board is NOT sold to Customer; all rights not expressly granted herein, including ownership of the Evaluation Board, are reserved by ADI. CONFIDENTIALITY. This Agreement and the Evaluation Board shall all be considered the confidential and proprietary information of ADI. Customer may not disclose or transfer any portion of the Evaluation Board to any other party for any reason. Upon discontinuation of use of the Evaluation Board or termination of this Agreement, Customer agrees to promptly return the Evaluation Board to ADI. ADDITIONAL RESTRICTIONS. Customer may not disassemble, decompile or reverse engineer chips on the Evaluation Board. Customer shall inform ADI of any occurred damages or any modifications or alterations it makes to the Evaluation Board, including but not limited to soldering or any other activity that affects the material content of the Evaluation Board. Modifications to the Evaluation Board must comply with applicable law, including but not limited to the RoHS Directive. TERMINATION. ADI may terminate this Agreement at any time upon giving written notice to Customer. Customer agrees to return to ADI the Evaluation Board at that time. LIMITATION OF LIABILITY. THE EVALUATION BOARD PROVIDED HEREUNDER IS PROVIDED "AS IS" AND ADI MAKES NO WARRANTIES OR REPRESENTATIONS OF ANY KIND WITH RESPECT TO IT. ADI SPECIFICALLY DISCLAIMS ANY REPRESENTATIONS, ENDORSEMENTS, GUARANTEES, OR WARRANTIES, EXPRESS OR IMPLIED, RELATED TO THE EVALUATION BOARD INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, TITLE, FITNESS FOR A PARTICULAR PURPOSE OR NONINFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS. IN NO EVENT WILL ADI AND ITS LICENSORS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES RESULTING FROM CUSTOMER'S POSSESSION OR USE OF THE EVALUATION BOARD, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DELAY COSTS, LABOR COSTS OR LOSS OF GOODWILL. ADI'S TOTAL LIABILITY FROM ANY AND ALL CAUSES SHALL BE LIMITED TO THE AMOUNT OF ONE HUNDRED US DOLLARS (\$100.00). EXPORT. Customer agrees that it will not directly or indirectly export the Evaluation Board to another country, and that it will comply with all applicable United States federal laws and regulations relating to exports. GOVERNING LAW. This Agreement shall be governed by and construed in accordance with the substantive laws of the Commonwealth of Massachusetts (excluding conflict of law rules). Any legal action regarding this Agreement will be heard in the state or federal courts having jurisdiction in Suffolk County, Massachusetts, and Customer hereby submits to the personal jurisdiction and venue of such courts. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this Agreement and is expressly disclaimed.

©2016 Analog Devices, Inc. All rights reserved. Trademarks and registered trademarks are the property of their respective owners UG14945-0-9/16(0)



www.analog.com